



Designation: D2318 – 20

Standard Test Method for Quinoline-Insoluble (QI) Content of Tar and Pitch¹

This standard is issued under the fixed designation D2318; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope*

1.1 This test method covers the determination of the quinoline-insoluble matter (QI) in tar and pitch.

1.2 Since this test method is empirical, strict adherence to all details of the procedure is necessary.

1.3 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.4 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety, health, and environmental practices and determine the applicability of regulatory limitations prior to use.* For hazards information, see Section 7.

1.5 *This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.*

2. Referenced Documents

2.1 *ASTM Standards:*²

[D71 Test Method for Relative Density of Solid Pitch and Asphalt \(Displacement Method\)](#)

[D95 Test Method for Water in Petroleum Products and Bituminous Materials by Distillation](#)

[D329 Specification for Acetone](#)

[D362 Specification for Industrial Grade Toluene \(Withdrawn 1989\)](#)³

[D850 Test Method for Distillation of Industrial Aromatic Hydrocarbons and Related Materials](#)

¹ This test method is under the jurisdiction of ASTM Committee D02 on Petroleum Products, Liquid Fuels, and Lubricants and is the direct responsibility of Subcommittee D02.05 on Properties of Fuels, Petroleum Coke and Carbon Material.

Current edition approved June 1, 2020. Published June 2020. Originally approved in 1964. Last previous edition approved in 2015 as D2318 – 15. DOI: 10.1520/D2318-20.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

³ The last approved version of this historical standard is referenced on www.astm.org.

[D4296 Practice for Sampling Pitch](#)

[D7280 Test Method for Quinoline-Insoluble \(QI\) Content of Tar and Pitch by Stainless Steel Crucible Filtration](#)

[E1 Specification for ASTM Liquid-in-Glass Thermometers](#)

[E11 Specification for Woven Wire Test Sieve Cloth and Test Sieves](#)

3. Summary of Test Method

3.1 The sample is digested in hot quinoline and filtered. The insoluble material is washed, dried, and weighed.

4. Significance and Use

4.1 This test method is useful in evaluating and characterizing tar and pitch, and as one element in establishing the uniformity of shipments and sources of supply.

5. Apparatus

5.1 *Filtering Crucibles*, porcelain, with fine-porosity bottom, 25 mL to 40 mL capacity, high-form, maximum pore diameter, 7 μm .

5.2 *Filter Apparatus*—Filter flask and tube with crucible adapter.

5.3 *Sieves*—U. S. Standard 600 μm (No. 30) and 250 μm (No. 60), conforming to Specification E11.

5.4 *Electric Hot Plate or Water Bath*, maintained at 75 °C \pm 5 °C.

6. Reagents and Materials

6.1 *Quinoline, Refined*, meeting the following requirements:

6.1.1 The quinoline shall distill from 5 % to 95 % within a range of 2 °C that shall include the temperature of 237.4 °C after corrections for barometric pressure and emergent stem have been applied. The distillation shall be carried out in accordance with Test Method D850 using a total immersion thermometer with a range from 195 °C to 305 °C, graduated in 0.5 °C, and conforming to the requirements for Thermometer 69C as described in Specification E1. Temperature measuring devices such as precision thermocouples, resistance temperature detectors (RTDs), and liquid-in-glass thermometers with equal or better accuracies in the appropriate temperature range may be used.

*A Summary of Changes section appears at the end of this standard

6.1.2 The quinoline shall have a specific gravity at 15.5/15.5 °C of 1.092 to 1.098, as determined by Test Method **D71**, or other method of equivalent accuracy.

6.1.3 The quinoline shall be clear and light in color and shall contain less than 0.5 % volume of water as determined by Test Method **D95**. If not, redistill the quinoline in all-glass apparatus, discarding the first 5 % and collecting the next 90 %. If the quinoline contains suspended matter but is clear, light in color, and contains less than 0.5 % water, filter the quinoline through a crucible containing 5 g of Celite Filter Aid.

6.1.4 Store the quinoline in a tightly closed, dark bottle.

6.2 *Toluene, Industrial Pure*, meeting Specification **D362**.

6.3 *Acetone*, meeting Specification **D329**.

6.4 *Concentrated Hydrochloric Acid*.

6.5 *Celite Analytical Filter Aid (CAFA)*—Dry to constant weight at 105 °C, and store in tightly stoppered container.

6.5.1 Do not use any other grade of filter aid because filtration characteristics may differ. CAFA is manufactured only by Manville Co. and distributed through scientific supply houses.

7. Hazards

7.1 Fumes of the solvents should be removed by means of proper hoods from all working areas. The working area should be kept free of sparks and flames. Quinoline fumes should not be inhaled, and prolonged contact with the skin should be avoided. Toluene is toxic and flammable.

7.2 Observe proper laboratory procedures for handling hydrochloric and diluting acid.

8. Bulk Sampling

8.1 Samples from shipments shall be taken in accordance with Practice **D4296** and shall be free of foreign substances. Thoroughly mix the sample immediately before removing a representative portion for the determination or for dehydration.

9. Dehydration of Sample

9.1 *Hard Pitch*—If the solid bulk sample contains free water, air-dry a representative portion in a forced draft oven at 50 °C.

9.2 *Soft Pitch*—If the presence of water is indicated by surface foam on heating, maintain a representative portion of the bulk sample at a temperature between 125 °C and 150 °C in an open container until the surface is free of foam. Take care not to overheat, and remove heat source immediately when foam subsides.

9.3 *Tar*—A wet tar sample may either be dehydrated or used as received as long as conditions stated in **9.3.1** and **9.3.2** are met.

9.3.1 Dehydrate a representative portion of the bulk sample at atmospheric pressure using a simple side-arm distillation apparatus similar to the one in Test Method **D850** and stop the distillation when the temperature reaches 170 °C. Separate any oil from the water that has distilled over (if crystals are present, warm sufficiently to ensure their solution) and thoroughly mix

the oil with the residual tar in the still after the latter has cooled to a moderate temperature.

9.3.2 As an alternative to dehydration, the water content of the tar is determined by Test Method **D95**, and if the water content is less than 10 % by mass, the QI content is corrected to a dry-tar basis (see **13.2**). This alternative test method applies only to stable emulsions of water in tar, that is, no water separates when the tar sample is left undisturbed for 24 h at room temperature.

10. Preparation of Working Sample

10.1 *Hard Pitch*—If the pitch can be crushed at room temperature, prepare a 20 g working sample by suitable crushing, mixing, and quartering of a representative portion of the dry sample. The crushing can be done with a small jaw crusher and a mullite mortar and pestle. No particle in the representative sample shall be larger than 5 mm in any dimension. Crush this sample so that *all of it* will pass the 250 µm (No. 60) sieve but will have a minimum of fine particles. Store the sieved working sample in a tightly closed container and use within 24 h (see **10.4**).

10.2 *Soft Pitch*—If the pitch is too soft to grind and too sticky to mix, heat a representative portion of the dry sample to the lowest temperature that will permit passage through the 600 µm (No. 30) sieve, taking care to avoid excessive loss of volatile matter. Do not exceed 10 min for this melting period. Pass the heated sample through the 600 µm (No. 30) sieve to remove foreign matter.

10.3 *Tar*—Heat a representative portion of the dry tar to the lowest temperature that will permit passage through the 600 µm (No. 30) sieve, then filter through this sieve to remove foreign matter.

10.4 *Preservation of Samples*—Store samples as large lumps or as solidified melts in closed containers. Discard working samples 24 h after crushing and sieving as changes in composition sometimes occur in pulverized pitch.

11. Crucible Preparations

11.1 If the crucible, after thorough cleaning (see **11.2**), has been used for less than six determinations, clean it as follows: Remove the mat, wash the crucible with distilled water, dry, and ignite in a muffle furnace for 1 h at about 800 °C. Cool the crucible slowly by placing it in a drying oven for 1 h after removal from the furnace to prevent cracking and place it in a desiccator while still warm.

11.2 After the crucible has been used for six determinations, remove any residual ash from pores in the filtering area by boiling in 1 + 1 hydrochloric acid. Add equal volume of concentrated hydrochloric acid to distilled water. Then boil the crucible in distilled water, thoroughly back wash with distilled water, dry, and ignite as in **11.1**.

12. Procedure

12.1 Make and record all weighings to the nearest 1 mg.

12.2 Select a sample mass that will yield between 75 mg and 150 mg of matter insoluble in quinoline (QI), unless this

would require less than the minimum acceptable sample mass of 0.5 g, in which case 0.5 g shall be used.

12.3 Transfer 1 g \pm 0.1 g of dry CAFA to a clean, dry, filtering crucible. Weigh immediately, and record the mass of crucible plus CAFA.

12.4 Place the required amount of sample in a tared beaker and weigh. Calculate and record the mass of the sample. Transfer about half of the CAFA from the crucible to the beaker with sample. Distribute the remaining CAFA evenly over the bottom of the crucible.

12.5 Add 25 mL of quinoline to the beaker while stirring the mixture with a stirring rod or thermometer to break up lumps, then cover the beaker with a small watch glass. Place the beaker and a wash bottle containing quinoline on an electric hot plate or in a water bath maintained at 75 °C \pm 5 °C. (A suitable weight can be used to keep the beaker from being upset in the water bath.) Digest for at least 20 min. Occasionally stir the contents of the beaker to promote digestion. Check for completeness of digestion by inspecting the bottom of the beaker for undigested pitch.

12.6 Insert the filter tube with adapter in the filter flask, and place the previously prepared and tared crucible in the adapter. Carefully add sufficient quinoline to the crucible to wet the Celite thoroughly. Apply suction and form a mat of evenly distributed Celite. Maintain suction until filtration and subsequent washing with quinoline are completed.

12.7 Pour the hot quinoline-pitch mixture into the crucible, while the Celite in the crucible is still wet, without disturbing the mat. Stir the mixture in the beaker immediately before pouring successive portions into the crucible. Allow the contents to drain completely, but not to the extent that the insoluble material on the filter appears substantially dry.

12.8 Wash the beaker, thermometer, or stirring rod, and crucible with small portions (2 mL to 3 mL each) of quinoline at 75 °C \pm 5 °C from the wash bottle. Pass all the washes through the filter. Allow each wash to pass almost completely through the filter before the next is added. Use a suitable policeman to sweep the insoluble particles into the crucible. Repeat the quinoline washes until the filtrate is the same color as the quinoline used for washing. Twelve washings are usually enough.

12.9 After the final quinoline wash has passed through the filter, fill the crucible with toluene and wash with a total of 75 mL to 100 mL of toluene using suction. After all the toluene has passed through the filter, wash the contents of the crucible in the same manner with acetone. Maintain full suction for a minimum of 5 min after the acetone wash. Remove the crucible, and wipe the outside with a clean, soft cloth or tissue moistened with acetone.

12.9.1 During the quinoline and toluene washing do not allow the CAFA mat to get completely dry as the filtration rate may decrease considerably.

12.10 Place the filtering crucible in the drying oven at 105 °C to 110 °C and dry to constant weight (\pm 1 mg). When the hot crucible is removed from the drying oven it shall have no odor of quinoline. Transfer the crucible to the desiccator and

cool for 25 min, then weigh and record the weight of the filtering crucible and its contents (see 12.1).

12.10.1 Insoluble matter on the filter, after washing with acetone, should have no odor of quinoline, which is evidence of insufficient washing. If odor of quinoline is detectable, repeat the entire determination.

12.11 If the mass of matter insoluble in quinoline is less than 75 mg or more than 150 mg, repeat the determination with an adjusted sample mass of not less than 0.5 g (see 12.2).

13. Calculation

13.1 Calculate the QI content as follows:

$$\text{QI, mass \%} = [(A - B)/C] \times 100 \quad (1)$$

where:

- A = total mass of the filtering crucible and CAFA added to the crucible, and matter insoluble in quinoline,
- B = initial mass of the filtering crucible containing dried CAFA, and
- C = mass of sample taken for the determination.

13.2 If the QI was determined on a wet tar sample (see 9.3.2), correct the QI value determined in 13.1 to a dry-tar basis as follows:

$$\text{QI, mass \% (dry basis)} = \quad (2)$$

$$\frac{\text{QI, mass \% (wet basis)}}{(100 - \text{water content of tar, mass \%})} \times 100$$

14. Report

14.1 Report the QI content to the nearest 0.1 %.

15. Precision and Bias

15.1 The following criteria shall be used for judging the acceptability of results (95 % probability):

15.1.1 *Repeatability*—The difference between two independent results obtained by the same operator in a given laboratory applying the same test method with the same apparatus under constant operating conditions on identical test material within short intervals of time would exceed the following value with an approximate probability of 5 % (one case in 20 in the long run) in the normal and correct operation of the test method:

$$0.2 \%$$

15.1.2 *Reproducibility*—The difference between two single and independent results obtained by different operators applying the same test method in different laboratories using different apparatus on identical test material would exceed the following value with an approximate probability of 5 % (one case in 20 in the long run) in the normal and correct operation of the test method:

$$0.6 \%$$

15.2 *Bias*—This test method has no bias because the value of quinoline-insoluble is defined in terms of this test method.

15.3 *Relative Bias*—“t-test” performed on the QI results by this test method and those obtained by Test Method D7280 using a stainless steel crucible did not indicate any statistically significant difference at 95 % confidence level.

16. Keywords

16.1 coal-tar insolubles; pitch; QI; quinoline insolubles; tar

SUMMARY OF CHANGES

Subcommittee D02.05 has identified the location of selected changes to this standard since the last issue (D2318 – 15) that may impact the use of this standard. (Approved June 1, 2020.)

(1) Revised subsection **10.2**.

(2) Updated verbiage of Section **15**.

ASTM International takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM International Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org). Permission rights to photocopy the standard may also be secured from the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, Tel: (978) 646-2600; <http://www.copyright.com/>